



Get Mac id:

For the below procedure prior installation of INCA is required.


1. Click Etas License manager



2. Select Tools and Obtain License info.




- 3) Click Get License Info and note down the HostID.





Getting Mac from Command prompt.

1. In Windows Go to Start > Run




2. Type cmd and <open>. Type nbtstat -a <Computer name>




With Entitlement Id.

Open the link


<https://license.etas.com/flexnet/operationsportal/logon.do>




Click Check box and select activate.




Enter Mail id and address If the names displayed are different.



Click Add new host.



Enter mac id and click ok.



Click check box and Next

Generate Licenses

Node-locked Hosts

+ Select Existing Host + Add New Host + Remove

Host

68B599FAC469

Please enter values for the hosts and click Next to configure counts.

Cancel

Back

Next

Click check box and Next

Copies Available To Activate Without Upgrading Previous Fulfillments.

Available Activatable Copies: 1
Extra Activations Available: 0
Pending Copies: 0
Fulfill Count: 1

What kind of activation you want to perform on this host?

Upgrade Activate None

Please click Next to review.

Cancel

Back

Verify

Next

Click Generate

Host	Fulfill Count
68B599FAC469	1

Please review values and click Verify to validate the license. Or click Generate to generate the license.

Cancel

Back

Verify

Generate

Click Check box and save to file

+ Save to File				
<input type="checkbox"/> Type	Fulfillment ID	Activation ID	Product	License Hosts
<input checked="" type="checkbox"/>			ISW_INCA_LIC - MP Version 7.0, Qty/Copy 1	68B599FAC469
+ Save to File				

Open ETAS license manager.

At Menu <File> Browse and add the license file.